


CONTENTS

目次

MACHINE BED FRAME	縫紉機本體	1
BUSHINGS MECHANISM	套管機構	2
COVER (1)	蓋 (1)	3
COVER (2)	蓋 (2)	4
CRANK SHAFT DRIVE MECHANISM (1)	下軸機構 (1)	5
ARM SHAFT MECHANISM	上軸機構	6
NEEDLE BAR, NEEDLE GUARD MECHANISM	針棒，針受機構	7
LOOPER DRIVE MECHANISM	彎針機構	8
FEED MECHANISM	送布機構	9
CRANK SHAFT DRIVE MECHANISM (2)	下軸機構 (2)	10
/T/ DEVICE	/T/ 伺服馬達機構	11
PRESSER FOOT MECHANISM	壓腳機構	12
SPREADER MECHANISM	上飾線機構	13
THREAD TENSION MECHANISM	線鬆緊調整機構	14
NEEDLE & SPREADER THREAD HANDLING	針及上飾線過線機構	15
LOOPER THREAD HANDLING	彎針過線機構	16
LUBRICATION MECHANISM (1)	給油機構 (1)	17
LUBRICATION MECHANISM (2)	給油機構 (2)	18
HR DEVICE	冷卻裝置	19
ACCESSORIES	附件箱	20
Q DEVICE	標準喇叭包邊裝置	21
SPECIFIC PARTS (1)	專用配件(1)	22
ELECTRICAL TYPE PRESSER FOOT LEFTER	電磁式抬壓腳組	23
BOTTOM TRIMMER MECHANISM	底線切線刀機構	24
ELECTRICAL TYPE BOTTOM TRIMMER DRIVING MECHANISM	電磁式下切刀驅動機構	25
THREAD STAND	線架組	27
ATTACHMENT BOX	附件盒	28




MACHINE BED FRAME


縫紉機本體

1

Ref.	Parts			Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>
1	W1-1	Machine Frame	機殼	1
2	W1-2	Oil Sight Gauge	油量視鏡	1
3	W1-3	Bed Pin	機台支撐銷	4
4	W1-4	Screw (M6-1X20)	螺絲	4
5	W1-5	Plug	孔塞	1
6	W1-6	Plug	孔塞	1
7	W1-7	Plug	孔塞	1
8	W1-8	Plug	孔塞	1
9	W1-9	Plug	孔塞	1
10	W1-10	Plug	孔塞	2
11	W1-11	Plug	孔塞	1
12	W1-12	Oil Filter Screen	過濾油網	1
13	W1-13	Retaining Ring	扣環	1
14	W1-14	Felt	羊毛氈	1
15	W1-15	Plug	孔塞	3
16	W1-16	Screw (M4-0.7X6)	螺絲	2
17	W1-17	Cover	底蓋	1
18	W1-19	Plug	孔塞	1
19	W1-20	Rivet	鉚釘	4
20	W1-21	Model Plate	型號銘牌	1
21	W1-22	Tube	油管	1
22	W1-25	Name Plate	銘牌	1
23	W1-27	Warning Sticker	警告貼紙	1
24	W1-29	Screw (M6-1X6)	螺絲	2
25	W1-30	Warning Sticker	警告貼紙	1
26	W1-31	Oil Seal	油封	1
27	W1-32	Sewing Maching Supprting Block	機座	1
28	W1-33	Sewing Head Cover (Right)	車頭後蓋	1



Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>	
1	W2-1	Pin	開口銷	1	
2	W2-2	Needle Bar Bushing(Lower)	針柱套管(下)	1	
3	W2-3	Oil Seal	油封	1	
4	W2-4	Needle Bar Bushing(Upper)	針柱套管(上)	1	
5	W2-5	Bushing	銅套管	2	
6	W2-6	Oil Seal	油封	1	
7	W2-7	Bushing	銅套管	1	
8	W2-8	Bushing	銅套管	1	
9	W2-9	Bushing	銅套管	2	
10	W2-10	Bushing	銅套管	1	
11	W2-11	Bushing	銅套管	1	
12	W2-12	Bushing	銅套管	1	
13	W2-13	Oil Seal	油封	1	
14	W2-14	Bushing	軸襯套	1	
15	W2-15	Bushing	軸襯套	1	
16	W2-16	Bushing	軸襯套	1	
17	W2-17	Bushing	軸襯套	1	
18	W2-18	Bushing	軸襯套	1	
19	W2-19	Bushing	軸襯套	1	
20	W2-20	Bushing	軸襯套	1	
21	W2-21	Bushing	軸襯套	1	
22	W2-22	Bushing	軸襯套	1	
23	W2-23	Bushing	軸襯套	1	
24	W2-24	Bushing	軸襯套	1	




COVER (1)


蓋 (1)

3


Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>	
1	W3-1	Sewing Head Cover (Top)	車頭上蓋	1	
2	W3-2	O-Ring	O型橡膠環	1	
3	W3-3	Oil Sight Window	油鏡	1	
4	W3-4	Gasket	止油襯墊	1	
5	W3-5	Screw (M4-0.7X12)	螺絲	12	
6	W3-6	Sewing Head Cover (Left)	車頭前蓋	1	
7	W3-7	Plug	孔塞	1	
8	W3-8	O-Ring	防油襯環	1	
9	W3-9	Screw (M4-0.7X8)	螺絲	1	
10	W3-10	Name Plate	銘牌	1	
11	W3-11	Sewing Head Cover (Rear)	車頭後側蓋	1	
12	W3-12	Gasket	止油襯墊	1	
13	W3-13	Screw (M6-1X10)	螺絲	8	
14	W3-14	Name Plate	銘牌	1	
15	W3-15	Thread Guide	導線片	1	
16	W3-16	Thread Takeup Cover	收線保護蓋	1	
17	W3-17	Screw (M5-0.8X14)	螺絲	1	
18	W3-18	Cord Clamp	線套	1	
19	W3-19	Pulley Cover	皮帶輪蓋	1	
20	W3-20	Screw (M5-0.8X60)	螺絲	2	
21	W3-21	Screw (M4-0.7X4)	螺絲	1	
22	W3-22	Arm Cover(Top) Assembly	車頭上蓋組	1	
23	W3-23	Bracket	護目鏡托架	1	
24	W3-24	Screw (M4-0.7X8)	螺絲	2	
25	W3-25	Washer	墊片	2	
26	W3-26	Bracket	護目鏡托架	1	
27	W3-27	Screw	段付螺絲	1	
28	W3-28	Washer	波浪華司	1	
29	W3-29	Eye Guard	護目鏡	1	
30	W3-30	Screw (M3-0.5X5)	螺絲	2	
31	W3-31	Washer	墊片	2	
32	W3-32	Nut	螺帽	1	
33	W3-33	Arm Cover(Top) Assembly	車頭前蓋組	1	
34	W3-34	Bracket Assembly	護目鏡組	1	
35	W3-35	Screw (M5-0.8X5)	螺絲	1	




Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>	
1	W4-1	Top Cover	上 蓋	1	
2	W4-2	Top Cover Gasket	上蓋防油墊片	1	
3	W4-3	Screw (M4-0.7X8)	螺絲	8	
4	W4-4	Flat Spring	止動片	1	
5	W4-5	Screw (M4-0.7X8)	螺絲	7	
6	W4-6	Bed Cover	下座上蓋	1	
7	W4-7	Plug	孔塞	1	
8	W4-8	Slide Plate	滑板	1	
9	W4-9	Bracket / Stitch Plate	針板座	1	
10	W4-10	Screw (M3-0.5X6)	螺絲	2	
11	W4-11	Positioning Bushing	定位襯套	2	
12	W4-12	Flat Spring	止動片	1	
13	W4-13	Screw (M4-0.7X4)	螺絲	2	
14	W4-14	Side Cover	側蓋板(下)	1	
15	W4-15	Screw (M4-0.7X12)	螺絲	2	
16	W4-16	Side Cover	側蓋板(上)	1	
17	W4-17	Bracket / Stitch Plate	針板座	1	
18	W4-18	Cover Plate Gasket	前蓋板防油墊	1	
19	W4-19	Pin	固定銷	1	
20	W4-20	Top Cover Assembly	上蓋組	1	
21	W4-21	Cover Plate Assembly	前蓋板組	1	
22	W4-22	Bed Cover Assembly	下座上蓋組	1	
23	W4-23	Slide Plate	滑板	1	
24	W4-24	Thread Guide	導線片	1	



Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>	
1	W5-1	Crankshaft	偏心軸	1	
2	W5-2	Screw (M4-0.7X4)	螺絲	1	
3	W5-3	Screw (M4-0.7X12)	螺絲	2	
4	W5-5	Main Shaft	主軸	1	
5	W5-6	Screw (M6-0.75X4)	螺絲	2	
6	W5-7	Washer	墊片	2	
7	W5-8	Connection	連桿	1	
8	W5-10	Crank	擺動臂	1	
9	W5-11	Screw (M6-0.75X15)	螺絲	1	
10	W5-12	Bearing	培林	1	
11	W5-13	Screw (M6-0.75X5)	螺絲	5	
12	W5-14	Bushing	軸承襯套	1	
13	W5-15	Bushing	軸承襯套	1	
14	W5-16	Timing Belt	時規皮帶	1	
15	W5-17	Bushing	軸承襯套	1	
16	W5-18	Gear Wheel	齒輪	1	
17	W5-19	Bearing	培林	1	
18	W5-20	Screw (M6-0.75X8)	螺絲	1	
19	W5-21	Set Plate	止動板	1	
20	W5-22	Screw (M4-0.7X8)	螺絲	2	
21	W5-23	Screw (M6-1X8)	螺絲	1	
22	W5-24	Screw (M6-1X10)	螺絲	1	
23	W5-25	Screw (M6-1X6)	螺絲	3	
24	W5-26	Pulley	皮帶輪	1	
25	W5-27	O-Ring	O型油環	2	
26	W5-28	Bearing	培林	1	
27	W5-29	Screw (M4-0.7X12)	螺絲	2	
28	W5-30	O-Ring	O型油環	2	
29	W5-31	Crankshaft Assembly	偏心軸組	1	
30	W5-32	Bushing Assembly	軸承襯套組	1	
31	W5-33	Bushing Assembly	軸承襯套組	1	
32	W5-34	Bushing Assembly	軸承襯套封組	1	
33	W5-35	Bushing Assembly	軸承襯套組	1	
34	W5-36	Machine Pulley Assembly	皮帶輪組	1	
35	W5-37	Connection Assembly	連桿組	1	
36	W5-38	Connection Assembly	連桿組	1	




Ref.	Parts				Amt.
No.	No.	Description	品 名	Req.	
1	W6-1	Motion	平衡錘	1	
2	W6-2	Bushing	軸襯套	1	
3	W6-3	Screw (M5-0.8X10)	螺絲	2	
4	W6-4	Screw (5/16-24X16)	螺絲	1	
5	W6-5	Screw (M6-1X6)	螺絲	1	
6	W6-6	Screw (M6-1X6)	螺絲	1	
7	W6-7	Bearing	培林	2	
8	W6-8	Crankshaft	偏心軸	1	
9	W6-9	Connection	連桿	1	
10	W6-10	Screw (M4-0.7X6)	螺絲	4	
11	W6-11	Screw (5/16-24X19)	螺絲	1	
12	W6-12	Crank	曲柄	1	
13	W6-13	Screw (M6-0.75X12)	螺絲	1	
14	W6-14	Balance Weight	平衡錘	1	
15	W6-15	Screw (M5-0.8X5)	螺絲	2	
16	W6-16	Crankshaft Coupling	偏心軸襯套	1	
17	W6-17	Handwheel Mark	手推輪商標銘牌	1	
18	W6-18	Screw (M6-1X6)	螺絲	7	
19	W6-19	Shft	軸	1	
20	W6-20	Bearing	培林	2	
21	W6-21	O-Ring	O型油環	4	
22	W6-22	Handwheel	手輪	1	
23	W6-23	Bushing	軸襯套	1	
24	W6-25	Gear Wheel	齒輪	1	
25	W6-26	Screw (M6-1X8)	螺絲	2	
26	W6-27	Crankshaft Assembly	偏心軸組	1	
27	W6-28	Bushing Assembly	軸承襯套組	1	
28	W6-29	Gear (Upper) Assembly	時規齒輪組	1	
29	W6-30	Bushing Assembly	軸承襯套組	1	
30	W6-31	Connection	連桿組	1	



Ref.	Parts			Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>
1	W7-1	Needle Bar	針棒	1
2	W7-2	Needle Bar Clamp	針棒連桿	1
3	W7-3	Screw (11/64-40X10.5)	螺絲	1
4	W7-4	Link	連桿	1
5	W7-5	Pin	插銷	1
6	W7-6	Needle Bearing	滾針軸承	1
7	W7-7	Washer	墊片	1
8	W7-8	Guide Block	導引滑塊	1
9	W7-9	Guide	導引座	1
10	W7-10	Screw (M4-0.7X12)	螺絲	3
11	W7-11	Screw (M3-0.5X2.3)	螺絲	1
12	W7-12	Latch	扣環	1
13	W7-13	Felt	羊毛氈	1
14	W7-14	Screw (M10-1X3.2)	螺絲	1
15	W7-15	Spring	彈簧	1
16	W7-16	Thread Guide	導線片	1
17	W7-17	Needle Holder	針鎗	1
18	W7-18	Needle	針	3
19	W7-19	Screw (M3-0.5X3)	螺絲	4
20	W7-20	Needle Plate	針板	1
21	W7-21	Screw (9/64-40X4.5)	螺絲	2
22	W7-22	Screw (M4-0.7X4)	螺絲	4
23	W7-23	Eccentric	偏心襯套	1
24	W7-24	Screw (M4-0.7X6)	螺絲	1
25	W7-25	Lever	曲柄	1
26	W7-26	Needle Guard (Rear)	針受(後)	1
27	W7-27	Needle Guard (Rear)	針受台(後)	1
28	W7-28	Needle Guard (Front)	針受(前)	1
29	W7-29	Tension Disc	夾線片	1
30	W7-30	Thread Guide	導線片	1
31	W7-31	Lever	曲柄	1
32	W7-32	Screw (M3.5-0.6X8)	螺絲	1
33	W7-33	Needle Guard (Front)	針受台(前)	1
34	W7-34	Thread Guide	撥線桿	1
35	W7-35	Screw (1/8-44X4)	螺絲	1
36	W7-36	Needle Bar Assembly	針棒組	1
37	W7-37	Needle Holder Assembly	針鎗組	1
38	W7-38	Guide Assembly	導引座組	1
39	W7-39	Needle Plate Assembly	針板座組	1
40	W7-40	Needle Guard (Rear) Assembly	針受台(後)組	1

NEEDLE BAR, NEEDLE GUARD MECHANISM針棒，針受機構**7**

Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>		<u>Req.</u>
41	W7-41	Needle Guard (Front) Assembly	針受台(前)組		1
42	W7-42	Link Assembly	連桿組		1
43	W7-43	Eccentric Assembly	偏心襯套組		1
44	W7-44	Washer	墊片		3
45	W7-45	Needle Plate	針板(薄料用)		1
46	W7-46	Needle Plate	針板(立骨用)		1




Ref.	Parts				Amt.
No.	No.	Description	品 名	Req.	
1	W8-1	Screw (M6-0.75X5)	螺絲	1	
2	W8-2	Eccentric	偏心軸	1	
3	W8-3	Nut	螺帽	1	
4	W8-4	Needle Bearing	滾針軸承	1	
5	W8-5	Rod	連桿	1	
6	W8-6	Pin	螺椿	1	
7	W8-7	Washer	墊片	1	
8	W8-8	Spring Washer	彈簧墊片	1	
9	W8-9	Guide / Looper Shaft	勾針基底	1	
10	W8-10	Screw (M6-0.75X15)	內六角窩頭螺絲	1	
11	W8-11	Screw (M4-0.7X12)	螺絲	2	
12	W8-12	Screw (M4-0.7X4)	螺絲	2	
13	W8-13	Looper Shaft	下勾針主軸	1	
14	W8-14	Washer	墊片	1	
15	W8-15	Screw (M4-0.7X10)	螺絲	1	
16	W8-16	Screw (M6-1X6)	螺絲	2	
17	W8-17	Washer	墊片	1	
18	W8-18	Lever	擺動臂	1	
19	W8-19	Holder	左撥動塊	1	
20	W8-20	Washer	墊片	2	
21	W8-21	Slider	導引滑塊	1	
22	W8-22	Pin	定位銷	1	
23	W8-23	Holder	右撥動塊	1	
24	W8-24	Washer	墊片	2	
25	W8-25	Shaft	軸	1	
26	W8-26	Looper Bar Bushing	下勾針驅動軸襯套	1	
27	W8-27	Screw (M4-0.7X4)	螺絲	1	
28	W8-28	O-Ring	油環	1	
29	W8-29	Shaft	軸	1	
30	W8-30	Plug	油塞	2	
31	W8-31	Looper Holder	勾針座	1	
32	W8-32	Screw (M3.5-0.6X10)	螺絲	1	
33	W8-33	Washer	墊片	1	
34	W8-34	Looper	勾針	1	
35	W8-35	Thread Guide	導線片	1	
36	W8-36	Oil Seal	油封	1	
37	W8-37	Looper Holder Assembly	勾針座組	1	
38	W8-38	Pin Assembly	螺椿組	1	
39	W8-39	Looper Bar Bushing Assembly	下勾針驅動軸襯套組	1	
40	W8-40	Holder Assembly	左撥動塊組	1	

LOOPER DRIVE MECHANISM

彎針機構

8

Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品</u>	<u>名</u>	<u>Req.</u>
41	W8-41	Pin	插	銷	1
42	W8-42	Holder Assembly	右	撥動塊組	1
43	W8-43	Looper Shaft Assembly	下	勾針主軸組	1
44	W8-44	Eccentric Assembly	偏	心軸組	1



FEED MECHANISM


送布機構

9

Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W9-1	Screw (M5-0.8X8)	螺絲	3
2	W9-2	Eccentric	偏心軸	1
3	W9-3	Screw (M5-0.8X12)	螺絲	1
4	W9-4	Needle Bearing	滾針軸承	1
5	W9-5	Needle Bearing	滾針軸承	1
6	W9-6	Ring	C型扣環	1
7	W9-7	Ring	C型扣環	1
8	W9-8	Rod	連桿	1
9	W9-9	Rod Assembly	連桿組	1
10	W9-10	Crank	曲柄	1
11	W9-11	Oil Felt	棉繩	2
12	W9-12	Washer	墊片	1
13	W9-13	Screw (M3-0.5X6)	螺絲	1
14	W9-14	Rod	連桿	1
15	W9-15	Link	連桿	1
16	W9-16	Link	連桿	1
17	W9-17	Screw (M6-0.75X5)	螺絲	2
18	W9-18	Pin	軸	2
19	W9-19	Screw (M5-0.8X10)	螺絲	1
20	W9-20	Felt	棉線	1
21	W9-21	Pin	軸	1
22	W9-22	O-Ring	油環	1
23	W9-23	Screw (M4-0.7X10)	螺絲	1
24	W9-24	Crank	曲柄	1
25	W9-25	Screw (M6-0.75X6)	螺絲	2
26	W9-26	Screw (M4-0.7X4)	螺絲	2
27	W9-27	Link	曲柄	1
28	W9-28	Liner	襯套	1
29	W9-29	Guide	軸	1
30	W9-30	Nut	螺帽	1
31	W9-31	Spring	彈簧	1
32	W9-32	Screw	螺椿	1
33	W9-33	Shaft	軸	1
34	W9-34	O-Ring	油環	2
35	W9-35	Lever	調節桿	1
36	W9-36	Screw Assembly	調節軸組	1
37	W9-37	Indication Plate	刻度蓋	1
38	W9-38	Screw (M4-0.7X10)	螺絲	2
39	W9-39	Screw	調節軸	1
40	W9-40	Ring	C型扣環	1

FEED MECHANISM送布機構**9**

Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>		<u>Req.</u>
41	W9-41	Ring	C型扣環		1
42	W9-42	Link Assembly	曲柄組		1
43	W9-43	Pin	插銷		1
44	W9-44	Lever Assembly	調節桿組		1
45	W9-45	Sticker	貼紙		1
46	W9-46	Eccentric Assembly	偏心軸組		1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W10-1	Link Assembly	送布齒台座組	1
2	W10-2	Oil Wick	給油線	1
3	W10-3	Screw (M2.5-0.45X5)	螺絲	1
4	W10-4	Crankshaft	軸	1
5	W10-5	Screw (M6-0.75X5)	螺絲	2
6	W10-6	Oil Seal	油封	1
7	W10-7	Screw (M6-0.75X4)	螺絲	2
8	W10-8	Collar	定位套環	2
9	W10-9	Screw (M5-0.8X5)	螺絲	2
10	W10-10	Screw (M6-1X6)	螺絲	1
11	W10-11	Crankshaft Assembly	軸組	1
12	W10-12	Crank	曲柄	1
13	W10-13	Main Feed Dog	主送布齒	1
14	W10-14	Crank Assembly	曲柄組	1
15	W10-15	Collar	定位套環	1
16	W10-16	Screw (M4-0.7X8)	螺絲	2
17	W10-17	Block	滑塊	1
18	W10-18	Block	滑塊	1
19	W10-19	Differential Feed Dog	差動送布齒	1
20	W10-20	Screw (M4-0.7X8)	螺絲	6
21	W10-21	Pin	銷	2
22	W10-22	Crank Pin	滑塊	1
23	W10-23	Differential Feed Rocker Lever	送料具差動搖臂	1
24	W10-24	Main Feed Bar	主送布齒台	1
25	W10-25	Differential Feed Bar	差動送布齒台	1
26	W10-26	Differential Feed Dog (Middle)	差動齒(中間小齒)	1
27	W10-27	Feed Dog Bar, C.Set	送料具固定座總成	1
28	W10-28	Guide	固定板	1
29	W10-29	Differential Feed Rocker Lever Assembly	送料具差動搖臂組	1
30	W10-30	Guide (Right)	止動塊	1
31	W10-31	Crankshaft	送布齒主軸	1
32	W10-32	Guide	固定板	1
33	W10-33	Washer	墊片	2
34	W10-34	Link	連桿	1
35	W10-35	Screw (M4-0.7X18)	螺絲	1
36	W10-36	Block	滑塊	1
37	W10-37	Driving Connection Bushing	驅動連桿襯套	1
38	W10-38	Collar Assembly	定位套環組	2
39	W10-39	Oil Wick	給油線	1
40	W10-40	Crankshaft Assembly	送布齒主軸組	1

CRANK SHAFT DRIVE MECHANISM (2)

下軸機構 (2)


10

Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>		<u>Req.</u>
41	W10-41	Collar Assembly	定位套環組		1
42	W10-42	Washer	墊片		2
43	W10-43	Differential Feed Dog (Middle)	差動齒(中間小齒)(立骨用)		1
44	W10-44	Pin	大頭針		2
45	W10-45	Oil Wick	油芯		1
46	W10-46	Link Assembly	連桿組		1




Ref.	Parts				Amt.
No.	No.	Description	品 名		Req.
1	W11-1	Directly Driving Type Mini-Servo Motor	微型伺服馬達		1
2	W11-2	Washer	墊片		3
3	W11-3	Guide	固定板		1
4	W11-4	Handwheel	手輪		1
5	W11-5	Screw (M5-0.8X8)	螺絲		2
6	W11-6	Guide	固定板		1
7	W11-7	Screw (9/64-40X7)	螺絲		3
8	W11-8	Cover	護蓋		1
9	W11-9	Screw (M5-0.8X14)	螺絲		2
10	W11-10	Cord Clamp	線套		1
11	W11-11	Cover	護蓋		1
12	W11-12	Ventilator	風扇		1
13	W11-13	Screw (M5-0.8X12)	螺絲		4
14	W11-14	Silencer	消音器		2
15	W11-15	Control Box	控制箱		1
16	W11-16	Lamp	燈		1
17	W11-17	Screw (M4-0.7X6)	螺絲		7
18	W11-18	Guide	固定基座		1
19	W11-19	Screw (M5-0.8X8)	螺絲		1
20	W11-20	Washer	墊片		2
21	W11-21	Retaining Ring	扣環		1
22	W11-23	Screw (M3-0.5X5)	螺絲		3
23	W11-24	Screw (M4-0.7X8)	螺絲		4
24	W11-28	IC Guide	IC板		1
25	W11-29	Plate	感光板		1
26	W11-30	Plate	感光板		1
27	W11-31	Handwheel Assembly	手輪組		1


12




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W12-1	Adjusting Bar	調節棒	1
2	W12-2	Nut	調節螺帽	1
3	W12-3	Spring	彈簧	1
4	W12-4	Spring	彈簧	1
5	W12-5	Presser Bar	壓腳棒	1
6	W12-6	Seal Plng	油塞	2
7	W12-7	Presser Bar Clamp	壓腳棒導引塊	1
8	W12-8	Screw (11/64-40X11.5)	螺絲	1
9	W12-9	Guide	滑塊座	1
10	W12-10	Screw (M4-0.7X20)	螺絲	2
11	W12-11	Screw (9/64-40X7)	螺絲	1
12	W12-12	Adjusting Bar Assembly	調節棒組	1
13	W12-13	Lever	擺臂	1
14	W12-14	Collar	定位套環	1
15	W12-15	Screw (11/64-40X6)	螺絲	1
16	W12-16	Link	連接板	1
17	W12-17	Screw (3/16-32X3)	螺絲	2
18	W12-18	Spring	彈簧	1
19	W12-19	Collar	定位套環	1
20	W12-20	Screw (11/64-40X4)	螺絲	2
21	W12-21	Bell Crank (Upper)	上曲柄	1
22	W12-22	Screw (11/64-40X14.5)	螺絲	1
23	W12-23	Link	連接吊片	1
24	W12-24	Screw (11/64-40X4)	螺絲	2
25	W12-25	Bell Crank (Lower)	下曲柄	1
26	W12-26	Screw (1/4-40X7)	螺絲	1
27	W12-27	Shaft	軸	1
28	W12-28	Lever	壓腳提把	1
29	W12-29	Screw (M5-0.8X10)	螺絲	1
30	W12-30	Pin	插銷	1
31	W12-31	Bracket	壓腳行程調節托架	1
32	W12-32	Screw (M4-0.7X8)	螺絲	2
33	W12-33	Screw (M5-0.8X25)	螺絲	1
34	W12-34	Nut	螺帽	1
35	W12-35	Guide Assembly	滑塊座組	1
36	W12-36	Presser Foot Assembly	壓腳	1
37	W12-37	Link Assembly	連接吊片組	1
38	W12-38	Collar Assembly	定位套環組	1
39	W12-39	Collar Assembly	定位套環組	1
40	W12-40	Lever Assembly	壓腳提把組	1
41	W12-41	Bracket Assembly	壓腳行程調節托架組	1
42	W12-42	Lever Assembly	壓腳提把組	1
43	W12-43	Bracket Assembly	壓腳行程調節托架	1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W13-1	Eccentric	偏心襯套	1
2	W13-2	Screw (M4-0.7X8)	螺絲	2
3	W13-3	Connection	連桿	1
4	W13-4	Crank	曲柄	1
5	W13-5	Screw (M6-0.75X12)	螺絲	1
6	W13-6	Screw Pin	插銷	1
7	W13-7	Washer	墊片	1
8	W13-8	Nut	墊帽	1
9	W13-9	Shaft	軸	1
10	W13-10	Washer	墊片	1
11	W13-11	Ring	C型扣環	1
12	W13-12	Crank	曲柄	1
13	W13-13	Screw (M6-0.75X5)	螺絲	2
14	W13-14	Block	滑塊	1
15	W13-15	Needle Bearing	滾針軸承	1
16	W13-16	Collar	定位套環	1
17	W13-17	Screw (1/8-44X3.5)	螺絲	2
18	W13-18	Crankshaft	曲軸	1
19	W13-19	Felt	棉線	1
20	W13-20	Lever	彎針臂	1
21	W13-21	Screw (M4-0.7X10)	螺絲	1
22	W13-22	Screw (M4-0.7X12)	螺絲	1
23	W13-23	Spreader	上彎針	1
24	W13-24	Oil Guard	封油墊片	1
25	W13-25	Shaft Assembly	軸組	1
26	W13-26	Crank Assembly	曲柄組	1
27	W13-27	Crankshaft Assembly	曲柄組	1
28	W13-28	Crank Assembly	曲柄組	1
29	W13-29	Collar Assembly	定位套環組	1
30	W13-30	Lever Assembly	彎針臂組	1
31	W13-31	Eccentric Assembly	偏心襯套組	1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W14-1	Thread Guide	導線架	1
2	W14-2	Screw (M4-0.7X8)	螺絲	4
3	W14-3	Pipe	導線管	2
4	W14-4	Latch	導線管定位片	1
5	W14-5	Screw (M4-0.7X6)	螺絲	1
6	W14-6	Crank	曲柄	1
7	W14-7	Screw (M5-0.8X12)	螺絲	1
8	W14-8	Washer	墊片	2
9	W14-9	Lever	擺臂	1
10	W14-10	Collar	偏心定位套環	1
11	W14-11	Screw (11/64-40X12.5)	螺絲	1
12	W14-12	Bracket	鬆線裝置底座	1
13	W14-13	Thread Releaser	鬆線輔導板	1
14	W14-14	Pin	插銷	1
15	W14-15	Tension Control Mechanism	沙拉組	1
16	W14-16	Thread Guide	導線片	5
17	W14-17	Thread Guide	導線片	5
18	W14-18	Felt	羊毛氈	5
19	W14-19	Spring (Light)	彈簧(弱)	1
20	W14-20	Tension Post Collar	隔環	5
21	W14-21	Screw Stud	螺椿	5
22	W14-22	Tension Dist	夾線片	10
23	W14-23	Cup	彈簧護圈	5
24	W14-24	Spring (Heavy)	彈簧(強)	3
25	W14-25	Spring Bushing	棘齒輪	5
26	W14-26	Post Nut	鬆線調整螺帽	5
27	W14-27	Spring (Middle)	彈簧(中)	1
28	W14-28	Crank Assembly	曲柄組	1
29	W14-29	Thread Guide Assembly	導線組	1
30	W14-30	Lever Assembly	擺臂組	1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W15-1	Thread Takeup	導線片	1
2	W15-2	Screw (M4-0.7X8)	螺絲	8
3	W15-3	Washer	墊片	4
4	W15-4	Spring Washer	彈簧華司	1
5	W15-5	Lever Assembly	鬆動臂	1
6	W15-6	Screw (M5-0.8X16)	螺絲	1
7	W15-7	C-Ring	C型扣環	1
8	W15-8	Washer	墊片	1
9	W15-9	Screw (1/8-44*3.5)	螺絲	2
10	W15-10	Shaft	軸	1
11	W15-11	Screw (M4-0.7X8)	螺絲	1
12	W15-12	Spring Washer	彈簧華司	1
13	W15-13	Washer	墊片	1
14	W15-14	Thread Guide	導線片	1
15	W15-15	Screw (M4-0.7X7)	螺絲	1
16	W15-16	Thread Guide	導線片	1
17	W15-17	Collar	軸環	1
18	W15-18	Thread Support	導線輔助片	1
19	W15-19	Screw (M4-0.7X10)	螺絲	1
20	W15-20	Washer	墊片	2
21	W15-21	Thread Guide Bracket	夾線架	1
22	W15-22	Shaft Assembly	軸組	1
23	W15-23	Collar Assembly	軸環組	1
24	W15-24	Thread Guide Assembly	導線片組	1
25	W15-25	Thread Guide Assembly	導線片組	1
26	W15-26	Thread Guide Assembly	導線片組	1
27	W15-27	Tension Disc	夾線片	2
28	W15-28	Spring	彈簧	1
29	W15-29	Thread Takeup	導線片	1
30	W15-30	Screw (1/8-40X3.5)	螺絲	1
31	W15-31	Thread Guide	導線片	1
32	W15-32	Thread Guide	導線片	1
33	W15-33	Thread Guide	導線片	1






Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W16-1	Looper Thread Takeup	收線凸輪	1
2	W16-2	Screw (M4-0.7X4)	螺絲	4
3	W16-3	Bracket / Loper Thread Guide	導線架	1
4	W16-4	Thread Guide	導線片	1
5	W16-5	Washer	墊片	2
6	W16-6	Screw (M2.5-0.45X4)	螺絲	2
7	W16-7	Thread Guide	導線片	1
8	W16-8	Shaft	軸	1
9	W16-9	Screw (M6-1X6)	螺絲	4
10	W16-10	Coolar	套環	1
11	W16-11	Screw (M3-0.5X3)	螺絲	1
12	W16-12	Screw (M5-0.8X5)	螺絲	1
13	W16-13	Thread Support	撥線片	1
14	W16-14	Screw (M3-0.5X6)	螺絲	1
15	W16-15	Gear Wheel	齒輪	1
16	W16-16	Gear Wheel	齒輪	1
17	W16-17	Timing Belt	時規皮帶	1
18	W16-18	Feed Drive Shaft Cover	止油蓋	1
19	W16-19	Screw (11/64-40X7)	螺絲	3
20	W16-20	Shaft	軸	1
21	W16-21	Lever Assembly	收線凸輪組	1
22	W16-22	Gear Wheel Assembly	齒輪組	1
23	W16-23	Collar	定位套環	1
24	W16-24	Thread Eyelet	過線片	1
25	W16-25	Screw (M4-0.7X6)	螺絲	1
26	W16-26	Bearing	培林	2
27	W16-27	Ring	C型扣環	2
28	W16-28	Ring	C型扣環	1
29	W16-29	Gear Wheel Assembly	齒輪組	1
30	W16-30	Bracket / Looper Thread Guide Assembly	導線架組	1
31	W16-31	Collar Assembly	定位套環組	1



Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W17-1	Pipe	給油銅管	1
2	W17-2	Joint Screw	螺絲接管	1
3	W17-3	Tube	油管	1
4	W17-4	Joint	接頭	4
5	W17-5	Screw (M4-0.7X6)	螺絲	2
6	W17-6	Joint Screw	螺絲接管	2
7	W17-7	Pipe	銅管	1
8	W17-8	Felt	羊毛氈	1
9	W17-9	Screw (M5-0.8X5)	螺絲	1
10	W17-10	Felt	羊毛氈	1
11	W17-11	Cord Clamp	線套	1
12	W17-12	Screw (M4-0.7X6)	螺絲	3
13	W17-13	Oil Distributor Assembly	噴油管組	1
14	W17-14	Suction Pipe Bushing	回油管襯套	1
15	W17-15	Pipe Assembly	回油銅管組	1
16	W17-16	Nut	螺帽	1
17	W17-17	Tube	油管	2
18	W17-18	Pipe Assembly	銅管組	1
19	W17-19	Oil Release Plug	滴油座	1
20	W17-20	Guide	固定板	1
21	W17-21	Oil Distributor	噴油管	1
22	W17-22	Pipe Assembly	銅管組	1
23	W17-23	Pipe	回油銅管	1
24	W17-24	Pipe Assembly	給油銅管組	1
25	W17-25	Oil Tube	油管	1
26	W17-26	Oil Distributor	噴油管	1
27	W17-27	Pipe	銅管	1
28	W17-28	Felt	羊毛氈	1
29	W17-29	Joint Screw	螺絲接頭	1
30	W17-30	Oil Distributor Assembly	噴油管組	1
31	W17-31	Washer	墊片	6
32	W17-32	Oil Tube	油管	1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W18-1	Guide	固定板	1
2	W18-2	Oil Reservoir	油槽	1
3	W18-3	Gasket	防油墊片	1
4	W18-4	Screw (3/8-28X10)	螺絲	1
5	W18-5	Screw (M8-1.25X20)	螺絲	4
6	W18-6	O-Ring	油環	1
7	W18-7	Bracket	幫浦定位架	1
8	W18-8	Pump Body (Oppor)	幫浦本體上座	1
9	W18-9	Rotor	內轉子	2
10	W18-10	Rotor	外轉子	2
11	W18-11	Pump Body (Lower)	幫浦本體下座	1
12	W18-12	Screw (M5-0.8X8)	螺絲	1
13	W18-13	Shaft	幫浦軸	1
14	W18-14	Cover	幫浦底蓋	1
15	W18-15	Screw (M4-0.7X40)	螺絲	2
16	W18-16	Screw (M4-0.7X30)	螺絲	2
17	W18-17	Worm Wheel	齒輪	1
18	W18-18	Screw (M5-0.8X5)	螺絲	2
19	W18-19	Screw (M5-0.8X12)	螺絲	2
20	W18-20	Bracket /Oil Filter	螺樁	1
21	W18-21	Joint Screw	螺絲	2
22	W18-22	Oil Filter	濾網	1
23	W18-23	O-ring	O型油環	1
24	W18-24	Oil Filter Cover	濾網蓋	1
25	W18-25	Filter seal	濾網指示牌	1
26	W18-26	Screw (M4X0.7X12)	螺絲	3
27	W18-27	Pump Assembly	幫浦組	1
28	W18-28	Oil Filter Screen	過濾油網	1
29	W18-29	Cover	幫浦底蓋	1
30	W18-30	Oil Filter Cover Assembly	濾網蓋組	1




Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W19-1	Oil Reservoir	蓄油槽	1
2	W19-2	Cap	蓄油槽蓋	1
3	W19-3	Hinge Pin	開口銷	2
4	W19-4	Felt	羊毛氈	1
5	W19-5	Screw (M3.5-0.6X6)	螺絲	2
6	W19-6	Screw (1/8-44X6.5)	螺絲	4
7	W19-7	Silicone Oil Reservoir Com	油壺	1
8	W19-8	Cover	油壺蓋	1
9	W19-9	Needle Cooler (Lower)	針冷卻器	1
10	W19-10	Tube	油管	1
11	W19-11	Felt	羊毛氈	1
12	W19-12	Felt	羊毛氈	1
13	W19-13	Oil Wick	給油線	1
14	W19-14	Screw (M4-0.7*10)	螺絲	2
15	W19-15	Plug	鋼珠	1
16	W19-16	Thread Guide	導線片	1
17	W19-17	Thread Glide	導線桿	3
18	W19-18	Holder	導線桿座	1
19	W19-19	Screw (1/8-44X3.5)	螺絲	3
20	W19-20	Cover	油蓋	1
21	W19-21	Screw (3/32-56X3)	螺絲	2
22	W19-22	Stitch Unlocker Mounting Bracket	跳線彈簧架	1
23	W19-23	Stitch Unlocker Spring Holder	跳線彈簧調整固定鈕	1
24	W19-24	Stitch Unlocker Spring	跳線彈簧	1
25	W19-25	Pin	插銷	1
26	W19-26	Washer	墊片	1
27	W19-27	Screw (M4-0.7X8)	螺絲	2
28	W19-28	Screw (11/128-56X3)	螺絲	1
29	W19-29	Silicone Oil Reservoir Com. Ass.	插針散熱油壺組	1
30	W19-30	Oil Reservoir Assembly	蓄油槽組	1
31	W19-31	Cover Assembly	油蓋組	1


20




W20-1




W20-6



W20-14




W20-15



W20-16

選擇配備



W20-17



W20-18




W20-19



W20-20




W20-24



W20-22

選擇配備




W20-23



W20-21




W20-34




W20-26

選擇配備

變壓器




W20-27
選擇配備



W20-25

W20-35




ACCESSORIES


附件箱

20

Ref.	Parts				Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>		<u>Req.</u>
1	W20-1	Cushion Rubber	防振墊		4
2	W20-6	Screw Assembly	螺絲組		1
3	W20-14	Bracket	支撐架		2
4	W20-15	Screw Assembly	螺絲組		1
5	W20-16	Belt Cover Assembly	皮帶蓋組		1
6	W20-17	Oil	潤滑油		1
7	W20-18	Oiler	油壺		1
8	W20-19	Funnel	漏斗		1
9	W20-20	Parts Book	零件本		1
10	W20-21	Machine Cover	防塵罩		1
11	W20-22	Pedal Assembly	壓腳踏板組		1
12	W20-23	Screwdriver	螺絲起子		1
13	W20-24	Instruction Book	維修手冊		1
14	W20-25	Thread Stand Assembly	線架組		1
15	W20-26	Pulley Cover Assembly	皮帶輪蓋組		1
16	W20-27	Lamp Assembly	燈組		1
17	W20-33	Screw	木螺絲		3
18	W20-34	Drier	乾燥劑		1
19	W20-35	Guide Assembly	固定板組		1



Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W21-1	Tape Disc,C.Set	布條盤組	1
2	W21-2	Presser Foot Assembly	壓腳	1
3	W21-3	Rear Subplate	後包邊輔助板	1
4	W21-4	Screw (M6-1X6)	螺絲	2
5	W21-5	Washer	墊片	2
6	W21-6	Needle Plate	針板	1
7	W21-7	Main Feed Dog	主送布齒	1
8	W21-8	Differential Feed Dog	差動送布齒	1
9	W21-9	Bracket / Stitch Plate	針板座	1
10	W21-10	Front Subplate	前包邊輔助板	1
11	W21-11	Screw (M4-0.7X5)	螺絲	2
12	W21-12	Washer	墊片	6
13	W21-13	Auxiliary Plate/Front Cover	前蓋輔助板	1
14	W21-14	Screw (M4-0.7X4)	螺絲	2
15	W21-15	Screw	螺絲	2
16	W21-16	Binder	喇叭.包邊器 (同一般平台式喇叭)	1
17	W21-17	Binder Mount (Upper)	喇叭.包邊器架(上)	1
18	W21-18	Screw (M5-0.X8)	螺絲	2
19	W21-19	Washer	墊片	1
20	W21-20	Binder Mount (Lower)	喇叭.包邊器架(下)	1
21	W21-21	Tape Disc	布條盤	1
22	W21-22	Tape Disc Post Assembly	布條盤軸組	1
23	W21-23	Guider Bar Holder	導桿座	2
24	W21-24	Screw (M3-0.5X3)	螺絲	4
25	W21-25	Binding Cloth Guider Bar	滾條布導桿	2
26	W21-26	Binding Cloth Pension Bar	滾條布張力調整桿	2
27	W21-27	Collar	軸環	1
28	W21-28	Screw	螺絲	1
29	W21-29	Tape Disc Post	布條盤軸	1
30	W21-30	Tape Guide	布條安置架	1
31	W21-31	Screw	木螺絲	3
32	W21-32	Binding Cloth Guider	滾條布導架	1
33	W21-33	Nut	螺帽	2
34	W21-34	Screw (M4-0.7X8)	螺絲	6
35	W21-35	Screw (9/64-40X4.5)	螺絲	2
36	W21-36	Screw (M3-0.5X6)	螺絲	2
37	W21-37	Positioning Bushing	定位襯套	2
38	W21-38	Needle Plate Assembly	針板座組	1
39	W21-39	Binder, C.Set	標準喇叭包邊組	1




SPECIFIC PARTS (1)


專用配件(1)

22

Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W22-1	Front Cover	前 蓋	1
2	W22-2	Hinge	鉸 鍊	1
3	W22-3	Auxiliary Plate/Front Cover	防油 蓋	1
4	W22-4	Screw (M4-0.7X8)	螺 絲	3
5	W22-5	Screw	螺栓	1
6	W22-6	Spring	簧 片	2
7	W22-7	Pin	軸 承 銷	1
8	W22-8	Screw (M3-0.5X3)	螺 絲	2
9	W22-9	Screw (M4-0.7X8)	螺 絲	2
10	W22-10	Guide	固 定 板	1
11	W22-11	Screw (M5-0.8*10)	螺 絲	2
12	W22-12	Washer	墊 片	2
13	W22-13	Takeup Cover	凸 輪 蓋	1
14	W22-14	Screw (M4-0.7X6)	螺 絲	1
15	W22-15	Screw (M4-0.8X8)	螺 絲	2
16	W22-16	Washer	墊 片	2
17	W22-17	Fabric Edge Guide (Right)	右 檔 邊	2
18	W22-18	Fabric Edge Guide (Left)	左 檔 邊	1
19	W22-19	Screw (1/8-44X2.5)	螺 絲	2
20	W22-20	Folder Stand	折下擺座	1
21	W22-21	Folder Stand Assembly	折下擺組	1
22	W22-22	Front Cover Assembly	前 蓋 組	1
23	W22-23	Screw (9/64-40X5.5)	螺 絲	1
24	W22-24	Eccentric Pin	調 整 鈕	1
25	W22-25	Screw (M4-0.7X4)	螺 絲	1
26	W22-26	Cushion	防 振 墊	1
27	W22-27	Screw (M4-0.7X16)	螺 絲	2



Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W23-1	Washer	墊片	2
2	W23-2	Presser Foot Lifter Solenoid	抬壓腳電磁閥	1
3	W23-3	Solenoid Bracket	電磁閥吊架	1
4	W23-4	Washer	墊片	2
5	W23-5	Screw (M6-1X15)	螺絲	2
6	W23-6	Washer	墊片	2
7	W23-7	Magnet	磁鐵	1
8	W23-8	Washer	墊片	2
9	W23-9	Gvro Wheel	滾輪	1
10	W23-10	Nut	螺帽	1
11	W23-11	Nut	螺帽	2
12	W23-12	Band (12cm)	束帶(12cm)	1
13	W23-13	Screw (M5-0.8X12)	螺絲	8
14	W23-14	Screw (M4-0.7X4)	螺絲	1
15	W23-15	Synchroniser Place	定位感應器座	1
16	W23-16	Tension Release Lever	張力釋放槓桿	1
17	W23-17	Cord Clamp	線套	1
18	W23-18	Tension Release Connecting Plate	張力釋放連接板	1
19	W23-19	Screw (M4-0.7X6)	螺絲	7
20	W23-20	Tension Release Block	張力釋放滑塊	1
21	W23-21	Thread Pull-off Bar	過線鬆線桿	1
22	W23-22	Ring	C型扣環	1
23	W23-23	Thread Pull-off Bar Holder	過線鬆線桿固定座	1
24	W23-24	Screw (M4-0.7X4)	螺絲	1
25	W23-25	Screw (11/64-40X12.5)	螺絲	1
26	W23-26	Collar	偏心定位套環	1
27	W23-27	Lever	擺臂	1
28	W23-28	Cord Clamp	線套	2
29	W23-29	Thread Pull-off Evelet	過線鬆線架	1
30	W23-30	Screw (M3-0.5X4)	螺絲	5
31	W23-31	Hook	鬆線鉤	5
32	W23-32	Activity Shelf	活動架	1
33	W23-33	Screw (11/64-40X5)	螺絲	1
34	W23-34	Washer	墊片	1
35	W23-35	Synchroniser	定位感應器	1
36	W23-36	Tension Release Lever Assembly	張力釋放槓桿組	1
37	W23-37	Lever Assembly	擺臂組	1
38	W23-38	Plug	孔塞	1
39	W23-39	Presser Foot Lifter Solenoid Assembly	抬壓腳電磁閥	1




BOTTOM TRIMMER MECHANISM


底線切線刀機構

24

Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W24-1	Lower Knife Driving Lever	下切刀驅動連桿	1
2	W24-2	Connecting Block	連結滑塊	1
3	W24-3	Screw (9/64-40X8)	螺絲	1
4	W24-4	Screw (M4-0.7X8)	螺絲	1
5	W24-5	Screw (M4-0.7X2.5)	螺絲	2
6	W24-6	Lower Knife Carrier	下切刀托架	1
7	W24-7	Screw (M3-0.5X2.5)	螺絲	2
8	W24-8	Connecting Plug	下切刀插接頭	1
9	W24-9	Lower Moving Knife	下活動刀	1
10	W24-10	Lower Knife Holder	下切刀固定座	1
11	W24-11	Upper Fixing Knife Carrier	上固定刀托架	1
12	W24-12	Screw (M4-0.7X4)	螺絲	2
13	W24-13	Nut	螺帽	2
14	W24-14	Knife Guede Lever	切刀導引搖臂	2
15	W24-15	Knife Guede Lever Eccentric Ring	切刀導引搖臂偏心輪	2
16	W24-16	Screw (M4-0.7X7)	螺絲	2
17	W24-17	Clamp Spring	彈簧片	1
18	W24-18	Thread Guide	導線片	1
19	W24-19	Screw (M4-0.7X4)	螺絲	2
20	W24-20	Upper Knife Carrier Spring	上固定刀托架復進簧	1
21	W24-21	Screw (M4-0.7X2.6)	螺絲	1
22	W24-22	Looper Thread Guide	底線過線護槽	1
23	W24-23	Screw (M3-0.5X3)	螺絲	2
24	W24-24	Crank Chamber Cover	曲柄軸室蓋	1
25	W24-25	Screw (M2-0.4X4)	螺絲	2
26	W24-26	Upper Fixing Knife	上固定刀	1
27	W24-27	Screw (M2-0.4X6)	螺絲	2
28	W24-28	Screw (M2-0.4X10)	螺絲	1
29	W24-29	Screw (M2-0.4X3.5)	螺絲	1
30	W24-30	Upper Fixing Guide	上固定刀導引架	1
31	W24-31	Clamp Spring	夾緊彈簧片	1
32	W24-32	Clamp Spring Pressure	夾緊壓力彈簧刀片	1
33	W24-33	Clamp Spring Pressure Holder	夾緊壓力彈簧固定座	1
34	W24-34	Clamp Spring Pressure Adjusting Piece	壓力彈簧調整片	1
35	W24-35	Thread Guide	導線片	1
36	W24-37	Screw (M4-0.7X8)	螺絲	2
37	W24-38	Screw (M4-0.7X8)	螺絲	8
38	W24-39	Lower Knife, C.Set	下切刀組	1



Ref.	Parts				Amt.
No.	No.	Description	品 名		Req.
1	W25-1	Washer	墊片		2
2	W25-2	Trimming Solenoid Support	下切刀電磁閥座		1
3	W25-3	Screw (M6-1X15)	螺絲		2
4	W25-4	Trimming Solenoid	下切刀電磁閥		1
5	W25-5	Screw (M5-0.8X12)	螺絲		5
6	W25-6	Return Shaft	復進軸		1
7	W25-7	Spring	彈簧		1
8	W25-8	Spring	彈簧		1
9	W25-9	Screw (11/64-40X4)	螺絲		5
10	W25-10	Plunger	柱塞接頭		1
11	W25-11	Collar	定位套環		3
12	W25-12	Band (12cm)	束帶(12cm)		3
13	W25-13	Terminal Holder	端子台		1
14	W25-14	Terminal Thread	中繼線		1
15	W25-15	Cord Clamp	線套		2
16	W25-16	Screw (3/32-56X7)	螺絲		2
17	W25-17	Screw (M4-0.7X8)	螺絲		1
18	W25-18	Terminal Thread	中繼線		1
19	W25-19	Screw (M5-0.8X6)	螺絲		1
20	W25-20	Solenoid Dust-Proof Cover	電磁閥防塵套		1
21	W25-21	Solenoid Dust-Proof Cover	電磁閥防塵套		1
22	W25-22	Nut	螺帽		1
23	W25-23	Nut	螺帽		1
24	W25-24	Washer	墊片		1
25	W25-25	Rubber Cushion	避震膠墊		1
26	W25-26	Terminal Holder Assembly	端子台組		1




THREAD STAND


線架組

27

Ref.	Parts			Amt.
<u>No.</u>	<u>No.</u>	<u>Description</u>	<u>品 名</u>	<u>Req.</u>
1	W27-1	Thread Stand Ass.(5-Spools)	線架組	1



W28-1




W28-2



W28-3



W28-4*5



W28-6




W28-5


選擇配備




W28-7




W28-8



W28-10*4




W28-11



W28-23

選擇配備


(立骨用)




W28-28

W28-25

W28-27




W28-9




W28-13

選擇配備




W28-14



W28-15

選擇配備




W28-16

W28-26

W28-17

W28-18



W28-22

Ref.	Parts			Amt.
No.	No.	Description	品 名	Req.
1	W28-1	Attachment Box	附件盒	1
2	W28-2	Screwdriver	螺絲起子	1
3	W28-3	Thread Tweezers	穿線夾	1
4	W28-4	Needle	擊針	5
5	W28-5	Iron Chain	鐵鍊	1
6	W28-6	Threading Wire	穿線鐵絲	1
7	W28-7	Wrench	板手	1
8	W28-8	Wrench	板手	1
9	W28-9	Fabric Guide Assembly	檔塊組	1
10	W28-10	Band (12cm)	束帶(12公分)	4
11	W28-11	Oil Filter	濾網	1
12	W28-12	Bright Board For Hemming	折袖下擺用之冷光板	1
13	W28-13	Bright Board	冷光板組	1
14	W28-14	Hemming set	折下擺組	1
15	W28-15	Guide	固定板	1
16	W28-16	Hexagonal Wrench (1.5mm)	內六角板手(1.5mm)	1
17	W28-17	Hexagonal Wrench (3mm)	內六角板手(3mm)	1
18	W28-18	Hexagonal Wrench (5mm)	內六角板手(5mm)	1
19	W28-19	Screw (M2.6-0.45*4)	螺絲	2
20	W28-20	Fabric Guide(Left)	檔塊(左)	1
21	W28-21	Fabric Guide(Right)	檔塊(右)	1
22	W28-22	Screwdriver	螺絲起子	1
23	W28-23	Sewing Guide For Bulging Type Seams Coveri	立骨專用導布器	1
24	W28-24	Trans Former	變壓器	1
25	W28-25	Presser Foot Sewing Guide For Seams Coverin	車縫押骨用之押腳分刀器	1
26	W28-26	Hexagonal Wrench (2.5mm)	內六角板手(2.5mm)	1
27	W28-27	Sewing Guide For Flattening Type Seams Cove	導骨用導布器組	1
28	W28-28	Sewing Guide For Flattening Type Seams Cove	倒骨用導布器組(適用三線拷克骨)	1